

DISINCROSTANTE



DISHWASHERS DESCALER

- Descaling action
- Keeps dishwashers and washing machines perfectly efficient
- Very effective and rapid



Acid descaler ideal for the removal of scale in dishwashers and washing machines. Very quickly removes all calcareous residue. Suitable for HACCP use.

? HOW TO USE

- MECHANICAL USE: dilute the product directly in the tank of the machine and act a wash cycle.
- MANUAL USE: let the components to descale soak. Leave to act and rinse.

📄 DILUTION

Pure or 20% (2 L in 10 L of water).

🔍 TECHNICAL DATA

ASPECT: Clear liquid

COLOR: Pink

PERFUME: Technical

COV/VOC: 0,00%

PH	Active substance [%]	Density (g/ml)	Pressure (bar)	Viscosity (cP)	Total dry residue [%]
< 1,0	23 ± 1	1.126			

DISINCROSTANTE

⚠ WARNINGS

May be corrosive to metals. Harmful if swallowed. Causes severe skin burns and eye damage. Wash hands thoroughly after handling. Wear eye protection. IF SWALLOWED: Rinse mouth. Do NOT induce vomiting. IF ON SKIN (or hair): Take off immediately all contaminated clothing. Rinse skin with water or shower. IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing. Immediately call a POISON CENTER or doctor/physician. Absorb spillage to prevent material damage. Contains PHOSPHORIC ACID.



DANGER



WARNING

📝 NOTES

Do not use on calcareous surfaces (marble, terrazzo, marble composition and travertine, etc.). Before use, please always refer to the Technical Data Sheet and the Safety Data Sheet, with the exposure scenario, of the product. Use the PPE specified in the Safety Data Sheet. All liability is declined for any damage due to an improper product use. **Only for professional use. Safety data sheet available on request.**

📦 PACKAGING

Code	Size	Quantity	Pallet
7121	Kg 5	4	9x4=36